



Assembly Instructions

9FT Bronze Push Button Tilt Umbrella TMPL 3040 BEIGE

Manufactured by (TMPL) for Rooms To Go

SKU # 92830504


1.0 Part List

Code	Description	Qty
A	Upper Part of Umbrella Frame with canopy 	1
B	Lower Pole 	1


Please note:

1. We recommend that you should assemble this product with the assistance of another person; this will make assembly easier and will eliminate damage to the product or injury to persons during assembly.
2. Please put all parts on a non - abrasive floor before assembly, and follow assembly steps to assemble your newly purchased product correctly and efficiently.

2.0 Assembly Process




Insert the lower pole (B) into the upper umbrella(A)'s middle pole until the snap button locks into place.




Insert the assembled umbrella into secure umbrella base or table (not included).


3.0 Instruction




To open the umbrella turn the crank in a clockwise direction until the umbrella canopy has fully opened.



Press the umbrella tilt button to angle the umbrella in the preferred position. Release the button to maintain the desired angle.



Turn crank handle in counter clockwise direction to close the umbrella.



Always take umbrella down when not in use and avoid using the umbrella during high wind, snow or any other inclement weather.

9FT Bronze Push Button Tilt Umbrella TMPL 3040 BEIGE, SKU# 92830504