





# DANCE DÉCOR

**SKU# 99201661 TL74745RTG GOLD FLOOR LAMP WITH SCALLOP SHADE**



Hardware Pack Location(s): Follow the red rope outside one corner of master brown carton, the other end of the rope connected to the hardware bag.

## Hardware list

NO.	DESCRIPTION	IMAGE	QTY
1	Harp 5"W X 9"H		1
2	Finial 1"W X 1"H		1
3	SCREWS		9


DO NOT USE SUBSTITUTE PARTS. PLEASE CONTACT YOUR RETAIL STORE OR [WWW.ROOMSTOGO.COM](http://WWW.ROOMSTOGO.COM) WITH SERVICE OR PARTS REPLACEMENT REQUEST.

This product is manufactured by (STLO) for

**ROOMS TO GO® | KIDS**

# DANCE DÉCOR

**SKU# 99201661 TL74745RTG GOLD FLOOR LAMP WITH SCALLOP SHADE**



## ASSEMBLY INSTRUCTIONS

1. Carefully unpack parts from carton, remove covering from parts and check that all parts are included as shown in the illustration.
2. Use SCREWS (1) to secure the TUBE (2) onto the PLATE (5). Attach TUBE (3) onto TUBE (2), then attach TUBE (4) onto TUBE (3). Next, use SCREWS (1) to secure SOCKET (8) onto TUBE (4), then insert HARP (10) onto SADDLE (7).
3. Place the SHADE (11) onto HARP (10) and screw FINIAL (12) onto HARP (10) to fix shade tightly.
4. Install the BULB (9) into the SOCKET (8) (bulb not included).

## GENERAL PRODUCT INFORMATION

This lamp is meant for indoor use.  
Dry locations only.



### IMPORTANT SAFETY INSTRUCTIONS:

This portable luminaire has a polarized plug (one blade is wider than the other) as a safety feature to reduce risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted.

This product is for decorative use only - NOT A TOY.  
Do not alter the plug.  
Do not attempt to defeat this safety feature.

**BULB TYPE: one type A Max 100W bulb (bulb not included).**



## WARNING

**CHOKING HAZARD -- Small Parts**  
This piece contains small parts, not intended for children under 3 years of age.

DO NOT USE SUBSTITUTE PARTS. PLEASE CONTACT YOUR RETAIL STORE OR [WWW.ROOMSTOGO.COM](http://WWW.ROOMSTOGO.COM) WITH SERVICE OR PARTS REPLACEMENT REQUEST.

This product is manufactured by (STLO) for **ROOMS TO GO®** | **KIDS**

# DANCE DÉCOR

**SKU# 99201661 TL74745RTG GOLD FLOOR LAMP WITH SCALLOP SHADE**

## IMPORTANT SAFETY INSTRUCTIONS



**Read all instructions before using this furnishing.**

**DANGER - To reduce the risk of electric shock.**

- This portable lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock.
- This plug will fit in a polarized outlet only one way.
- If the plug does not fit fully in the outlet, reverse the plug.
- If it still does not fit, contact a qualified electrician.
- Never use with an extension cord unless the plug can be fully inserted.
- Do not alter the plug.

## INSTRUCCIONES DE SEGURIDAD IMPORANTES



**Leer todas las instrucciones antes de usar este mobiliario.**

**PELIGRO - Para reduce el riesgo de descargas eléctrica.**

- Esta lámpara portátil tiene un enchufe polarizado (una hoja es más ancha que la otra) como característica de seguridad para reducir el riesgo de descarga eléctrica.
- Este enchufe encajará en una salida polarizada de una sola manera.
- Si el enchufe no encaja completamente en el tomacorriente , invierta el enchufe.
- Si aún no encaja, comuníquese con un electricista calificado.
- Nunca lo use con un cable de extensión a menos que el enchufe se pueda insertar completamente.
- No altere el enchufe.

**DO NOT USE SUBSTITUTE PARTS. PLEASE CONTACT YOUR RETAIL STORE OR [WWW.ROOMSTOGO.COM](http://WWW.ROOMSTOGO.COM) WITH SERVICE OR PARTS REPLACEMENT REQUEST.**