


SERENGETI TABLE LAMP

TOV-G18366






TOV

SERENGETI

ASSEMBLY INSTRUCTIONS




PARTS LIST & HARDWARE LIST

| LABEL | DESCRIPTIONS | PICTURE | QTY |
|-------|--------------|--|-----|
| A | SHADE |  | 1X |
| B | TOP NUT |  | 1X |
| C | LAMP STAND |  | 1X |
| D | LAMP HARP |  | 1X |
| E | BASE |  | 1X |

PREPARATION


Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list. If any part is missing or damaged, do not attempt to assemble the product. Estimated Assembly Time: 10 minutes.



Step 1

Carefully place the lamp stand (B) over the lamp base (D) and rotate clockwise to tighten.

2



Step 2

Unscrew the top nut (C) from the harp (F) of the lamp.

Place the harp (F) over the bulb holder (I) and tighten with the help of plastic ring (S) by rotate clockwise.

Carefully place the shade (A) over the harp (F) and ensure that it is aligned so that the top nut can be re-screwed.

Slightly move the shade to check if it has been adequately tightened. If it feels loose screw in the top nut (C) until it is tightly screwed.

CARE & MAINTENANCE

1. Do not use acids or alkaline cleaning agents.
2. Sharp objects will damage and scratch the surface.
3. Wipe the surface with a soft, damp cloth.
4. Please make sure that you have all parts indicated before you begin assembly of this item
5. This item should be assembled on a soft surface to prevent scratching the finish during assembly
6. This item may require periodic tightening



Save all packaging until assembly is completed

Need a part? Call TOV at 516-888-3355 or email service@tovfurniture.com