Item # : W70FENSMD
Assembly Instructions

**Walker Edison**

General Assembly Guidelines

I.   Ensure that all parts and hardware are available before beginning assembly.

II.   Follow each step carefully to ensure the proper assembly of this product.

III.   Two people are recommended for ease in the assembly of this product.

IV.   The three main types of hardware used to assemble this product are: wood dowels, screws and bolts.

V.   The provided glue is to secure wood dowels in place. When first inserting dowels, locate the appropriate hole for the dowel, place a small amount of glue in the hole and insert the dowel. Wipe away excess glue immediately.

In future assembly steps when dowels are necessary to attach assembly parts together, place a small amount of glue on the end of the dowel before attaching parts together. Wipe away excess glue immediately.

VI.   A Phillips head screwdriver is required for the assembly of this product .

VII.   Power tools should not be used to assemble this product.

VIII.   Drill may be needed for securing product to wall.

Parts List

Hardware List

|					
A		Ø6x35mm	Cam bolt	8	pcs
B		Ø8x30mm	Wooden dowel	16	pcs
C		Ø15x11mm	Cam lock	8	pcs
D		Ø30mm	Sticker	8	pcs
E		Ø6x50mm	Screw	8	pcs
F		Ø1/4"x30mm	Bolt	12	pcs
G		Ø4x12mm	Screw	10	pcs
H		Ø1/4"x30mm	Bolt	4	pcs
J		M 4	Hex key	1	pc
K		Ø3x17mm	Screw	12	pcs
L			Plastic wedge	12	pcs
M		Ø3x15mm	Screw	4	pcs
N		Ø3x12mm	Screw	16	pcs
P			Shelf support pin	16	pcs
Q			Pulley	4	pcs
R		Ø4x38mm	Screw	4	pcs
S		Ø4x30mm	Screw	2	pcs
T			Plastic strap	2	pcs
U			Nut	2	pcs
V			Glue tube	1	pc

Philips head screwdriver required for assembly
(not included)

The hardware quantities listed above are required for proper assembly.
Some extra hardware may also have been included.

Step 1

A

1

Secure cam bolt (A) into part (1) with Philips head screwdriver as per diagram.

Step 2

B
B

B
B

B
B

B
B

5

6

7

8

B

B

B

B

B

B

B

B

B

B

B

B

Insert wooden dowel (B) into parts (5,6,7,8) as per diagram.

Step 3

Using Cam lock(C) secure parts (5,6) to part (1) with Philips head screwdriver as per diagram.

Step 4

Using Cam lock(C) secure parts (7,8) to part (1) with Philips head screwdriver as per diagram.

Step 5

Put parts (3,4) as per diagram.

Step 6

J

E

2

8

7

6

5

Using screw (E) attach part (2) into parts (5,6,7,8) with Hex key (J) as per diagram.

Step 7

Using Bolt (F) attach part (13) to part (14), then using bolt (F) attach part (13) to part (14) with Hex key (J) as per diagram.

Step 8

Using bolt (F) attach part (13) to part (2) with Hex key (J) ,then using screw (G) attach part (15) to part (2) with Philips head screwdriver as per diagram.

Step 9

13

13

5

H

J

H

H

8

13

J

13

Using bolt (H) attach part (13) to parts (5,8) with Hex key (J) as per diagram.

Step 10

L

L   K

Using screw (K) secure plastic wedge (L) with Philips head screwdriver as per diagram.

Step 11

D

Place sticker (D) cover the holes as per diagram .

Step 12

M

12

11

12

11

R

x 2

Place part (12) to part (11) ,then using screws (M,R) secure part (11) to part (12) with Philips head screwdriver as per diagram.

Step 13

N

N

Q

x 2

Using screw (N) attach Pulley (Q) to part (12) with Philips head screwdriver as per diagram.

Step 14

Q

12

x 2

Please kindly note that you can adjust the height of the wheels to make the door keeping good fit by adjusting the screw as per diagram.

Step 15

Insert the upper pins of part (11) into the groove of part(1) .Lift up the door in vertical position with the bottom panel (2) ,lay down the door and keep the wheels matching with the track in bottom panel as per diagram .

Step 16

Insert the upper pins of part(11) into the groove of part(1) .Lift up the door in vertical position with the bottom panel (2) ,lay down the door and keep the wheels matching with the track in bottom panel as per diagram .

Step 17

Slide the doors (11) to the left and right .If necessary , re-assemble the doors for a good fit and sliding smoothly.

Step 18

Please kindly note that you can adjust the height of the wheels to make the door keeping good fit by adjusting the screw as per diagram.

Step 19

Slide the doors (11) to the left and right .If necessary , re-assemble the doors for a good fit and sliding smoothly.

Step 20

5

6

7

9

9

10

Finished edge

P

P

Insert shelf support pin (P) into parts (5,6,7) as per diagram. Make sure you place the shelf support pins (P) in the same level. So the shelf is not titled .Put parts (9,10) into unit as per diagram. Tilt and rest the adjustable shelves (9,10) onto the shelf support pins .

Step 21

Slide the doors (11) to the left and right as per diagram.

Step 22

Finished edge

P

P

Insert shelf support pin (P) into parts (7,8) as per diagram. Make sure you place the shelf support pins (P) in the same level. So the shelf is not titled .Put part (10) into unit as per diagram. Tilt and rest the adjustable shelf (10) onto the shelf support pins .

Step 23

Position the assembled unit at the desired location ,if necessary adjust the floor leveler at the bottom of the support leg to level the unit .

Step 24

1

T

G

Using screw (G) attach Velcro strap (T) into part (1) with Philips head screwdriver as per diagram.

Step 25

WARNING

Wall

U

T

S

Using screw (S) attach Velcro strap (T) into Nut (U) to wall with Philips head screwdriver as per diagram.

Step 26

Final Assembly