


Thanks for purchasing this quality product. Be sure to check all packing materials carefully for small parts, which may have come loose inside the carton during shipment. Identify and count all parts and compare with the Hardware List below


Caution: Loosely pre-assemble all the bolts first. Do not fully turn until all bolts are inserted into the proper holes.



Step 1: Place the Top(Part A) on a clean, soft surface as a blanket or carpet. Assemble the Legs(Part B&C) to the Top by Bolt(Part E) and Washer(Part D), tighten with Allen Key(Part Z).



Step 2: After tightening all bolts, your product is ready for use.



PARTS LIST

PARTS LIST

NO.:	PIC	DESC	QTY
A		Top	1pc
B		Leg1	2 pcs
C		Leg2	2 pcs

NO.:	PIC	DESC	QTY
D		Washer	8 pcs
E		Bolt	8 pcs
Z		Allen Key	1 pc

Periodically check and make sure all bolts are fully tightened.