





<p>(A) x8</p>  <p>M4x35mm</p>	<p>(B) x8</p>  <p>Ø15x12mm</p>	<p>(C) x8</p>  <p>M6x35mm</p>	<p>(D) x16</p>  <p>Ø8x30mm</p>	<p>(E) x4</p>  <p>76x74mm</p>	<p>(F) x1</p>  <p>Ø24mm</p>	<p>(G) x1</p>  <p>M4x20mm</p>
<p>(H) x1</p>  <p>45x14mm</p>	<p>(I) x2</p>  <p>M3.5x14mm</p>	<p>(J) x2</p>  <p>Ø5x14mm</p>	<p>(K) x20</p>  <p>M4x12mm</p>	<p>(L) x4</p> 		



- 1** Attach piece 4 & 5 to piece 6 using wooden dowels (D), screws (A), cam dowels (C) and cam locks (B)





- 2** On piece 7, attach the door handles (F) using screws (G).





- 3** On piece 1, secure the catch (H) using screws (I). Use the pre-drilled holes for guidance.







- 4** Attach piece 3 and assembled 4,5,6 piece to piece 2 using wooden dowels (D), screws (A).






5 Turn the unit upside down, slot piece 8 into the ridges, put wooden dowels (D) on each part as shown.



6 Attach piece 1 to the unit using cam dowels (C) and cam locks (B). Connect door 7 using bar hinges (J).



7 Attach metal plate (E) to piece 2 using screws (K).



8 Tighten the leg (8) clockwise direction, add leg pad (L) as shown.

