


# Item # : AF44MOL2DR

## Assembly Instructions




Walker Edison®

*Please visit our website for the most current instructions, assembly tips, report damage, or request parts. [www.walkerediton.com](http://www.walkerediton.com)*


Revised 02/01/2020 (L)

# General Assembly Guidelines


- I. Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- IV. The three main types of hardware used to assemble this product are : wood dowels , screws and bolts.
- V. The provided glue is to secure wood dowels in place . When first inserting dowels , locate the appropriate hole for the dowel , place a small amount of glue in the hole and insert the dowel . Wipe away excess glue immediately.




In future assembly steps when dowels are necessary to attach assembly parts together , place a small amount of glue on the end of the dowel before attaching parts together . Wipe away excess glue immediately.















- VI. A Phillips head screwdriver is required for the assembly of this product .






- VII. Power tools should not be used to assemble this product .




# Parts List



# Hardware List


|   |   |           |                 |    |     |
|---|---|-----------|-----------------|----|-----|
| A |    | Ø8x30mm   | Wooden dowel    | 38 | pcs |
| B |    | Ø6x35mm   | Cam bolt        | 31 | pcs |
| C |    | Ø15x11mm  | Cam lock        | 23 | pcs |
| D |    | Ø15x9mm   | Cam lock        | 8  | pcs |
| E |    |           | Sticker         | 31 | pcs |
| F |    | Ø6x50mm   | Screw           | 21 | pcs |
| G |    | Ø6x12mm   | Bolt            | 20 | pcs |
| H |    | M4        | Hex Key         | 1  | pc  |
| J |    |           | Plastic stopper | 2  | pcs |
| K |    | Ø3.5x15mm | Screw           | 2  | pcs |
| L |  | Ø4x32mm   | Screw           | 8  | pcs |
| M |  |           | Glue tube       | 1  | pc  |



Philips head screwdriver required for assembly  
(not included)


*The hardware quantities listed above are required for proper assembly.  
Some extra hardware may also have been included.*

# Step 1




Secure cam bolt (B) into parts (1, 13) with Philips head screwdriver as per diagram.

# Step 2




Insert wooden dowel (A) into parts (3,4,5,6,7,8,9) ,then secure cam bolt (B) into parts (3,6) with Philips head screwdriver as per diagram.

## Step 3





Insert wooden dowel (A) into part (10), then secure cam bolt (B) into part (10). Using screw (K) attach Plastic stopper (J) to part (10) with philips head screwdriver as per diagram.

# Step 4





Using screw (F) attach part (10) into parts (7,8) with hex key (H) as per diagram.

# Step 5





Using cam lock(C) secure part (3) to parts(8,10) with Philips head screwdriver as per diagram.

# Step 6





Using cam lock(C) secure part (6) to parts(8,10) with Philips head screwdriver as per diagram.

# Step 7




Using cam lock(C) secure parts (3,4,6,7,8) to part (1) with Philips head screwdriver as per diagram.

# Step 8





put part (5) as per diagram ,then using cam lock(C) secure part (9) to part(10) with Philips head screwdriver as per diagram.

# Step 9




Using screw (F) attach part (2) into parts (3,4,5,6,9) with hex key (H) as per diagram.

# Step 10




Using bolt (G) attach parts (11,12) to part (2) with hex key (H) as per diagram.

# Step 11



Using screw (L) attach parts (14,16) to part (15) with Philips head screwdriver as per diagram.



# Step 12



x 2


Put part (17) as per diagram.

# Step 13




Using cam lock(D) attach parts (13) to part (14,16)with Philips head screwdriver as per diagram.

# Step 14




Place sticker (E) cover the holes as per diagram .

# Step 15




Insert the assembled drawers into the unit frame.

# Step 16



Position the assembled unit at the desired location ,if necessary adjust the floor leveler at the bottom of the support leg to level the unit .

# Step 17



# Final Assembly