



1 Attach the runners L to pieces 3 and 4 as shown. Use screws (D).




2 Then attach pieces 2, 3 and 4 to piece 5 using wooden dowels (K), screw (C).

A		10 PCS
B		10 PCS
C		10 PCS
D		12 PCS
E		2 PCS
F		10 PCS
G		12 PCS
H		1 PCS
I		2 PCS
J		2 PCS
K		12 PCS


L		1 PCS
	CL DL DR CR	




3 Slot piece 6 into the ridges, then attach piece 1 using wooden dowels (K), cam dowels (A) and cam locks (B).




4 Attach piece 14, 15 & 16 to piece 12 & 13 using screw (G) as shown.




5 Attach 2 section using screw (F).




6 Attach pieces 7, 8 & 9 using screws (C). Make sure that the built-in ridge is facing inwards and at the bottom.




7 On piece 10, attach the door handles (H) using screws (E).




8 Slot piece 11 into the ridges. First insert the cam locks (B) into the pre-drilled holes on parts 8 & 9. Then insert cam dowels (A) into each side, you then need to line up these screws with the pre-drilled holes on the front piece (10). Once attached, tighten the cam locks (B) using a cross-head screwdriver and ensure the piece is secure.



9 Turn the drawer upside down. Line up the holes on the outside pieces with the holes on the runners (LDR & LDL), secure to the drawer using screws (D).



10 Insert the drawer.



11

Secure the unit to a wall in your chosen location using wall plugs (I) and screws (J).

