


# Item # : AF3PCSCTST

## Assembly Instructions




Walker Edison®

Please visit our website for the most current instructions, assembly tips, report damage, or request parts. **[www.walkeredison.com](http://www.walkeredison.com)**

Revised 15/07/2020(C)


# General Assembly Guidelines

- I. Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- IV. The main type of hardware used to assemble this product are: bolts and screws.
- V. Power tools should not be used to assemble this product.




- VI. Drill may be needed for securing product to wall.

# Parts List



# Hardware List


A		M6x12mm	Bolt	24	pcs
B		M6x30mm	Bolt	10	pcs
C			Glass pad	6	pcs
D		M 4	Hex key	1	pc



Philips head screwdriver required for assembly  
(not included)


*The hardware quantities listed above are required for proper assembly.  
Some extra hardware may also have been included.*

# Step 1





Using bolt (B) attach part (3) to part (4) with Hex key (D) as per diagram.  
Note: Please do not fully tighten all bolts.

## Step 2




Using bolt (B) attach part (3) to part (4) with Hex key (D) as per diagram.

## Step 3



Using bolt (A) attach part (3) to part (2) with Hex key (D) as per diagram.  
Note: Fully tighten all bolts.


## Step 4



Tear off the glass pad (C) and place on the top of metal frame as per diagram.




## Step 5



Place part (1) on the top of part (2) carefully as per diagram.

## Step 6




x 2

Using bolt (A) attach part (6) to part (5) with Hex key (D) as per diagram.

Note: Please do not fully tighten all bolts.


## Step 7



x 2

Using bolt (B) attach part (7) to part (6) with Hex key (D) as per diagram.  
Note: please fully tighten all bolts.

## Step 8



## Final Assembly