


Item # : W60FPMX

Assembly Instructions




Walker Edison®

Please visit our website for the most current instructions, assembly tips, report damage,
or request parts. www.walkeredison.com


Revised 15/07/2019(L)

General Assembly Guidelines


- I. Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- IV. The three main types of hardware used to assemble this product are: wood dowels, screws and bolts.
- V. The provided glue is to secure wood dowels in place. When first inserting dowels, locate the appropriate hole for the dowel, place a small amount of glue in the hole and insert the dowel. Wipe away excess glue immediately.




In future assembly steps when dowels are necessary to attach assembly parts together, place a small amount of glue on the end of the dowel before attaching parts together. Wipe away excess glue immediately.



- VI. A Phillips head screwdriver is required for the assembly of this product .




- VII. Power tools should not be used to assemble this product.





- VIII. Drill may be needed for securing product to wall.

Parts List



Hardware List


A		Ø8x30mm	Wooden dowel	20 pcs
B		Ø6x35mm	Cam bolt	16 pcs
C		Ø15x11mm	Cam lock	16 pcs
D			Sticker	16 pcs
E		Ø6x50mm	Screw	6 pcs
F		M 4	Hex Key	1 pc
G		Ø6x15mm	Bolt	16 pcs
H		Ø6x15mm	Bolt	8 pcs
J			L shape bracket	8 pcs
K		Ø4x38mm	Screw	4 pcs
L			L shape bracket	2 pcs
M		Ø4x12mm	Screw	4 pcs
N			Glue tube	1 pc
P		F18V66L	Fireplace Insert	1 pc



Philips head screwdriver required for assembly
(not included)


*The hardware quantities listed above are required for proper assembly.
Some extra hardware may also have been included.*

Step 1




Using cam bolt (B) secure part (1) with Philips head screwdriver as per diagram.

Step 2




Insert wooden dowel (A) into parts (3,4,5,6) ,then using bolt (G) attach L shape bracket (J) into parts (3,4,5,6) with hex key (F) ,using cam lock (B) secure parts (3,4,5,6) with Philip head screwdriver as per diagram.

Step 3




Using bolt (H) attach part (11) into parts (3,4,5,6) with hex key (F) as per diagram.

Step 4




Using bolt (G) attach L shape bracket (J) into part (2) with hex key (F) as per diagram.

Step 5





Using screw (E) attach part (2) into part (14) with hex key (F) as per diagram.

Step 6





Insert wooden dowel (A) into parts (7,8,12) ,then using cam bolt (B) secure parts (7,8,9,10) with Philips head screwdriver as per diagram.

Step 7




Using cam lock (C) secure parts (9,10) into parts (7,8) with Philips head screwdriver as per diagram.

Step 8





Using cam lock (C) secure part (12) into parts (7,8) with Philips head screwdriver as per diagram.

Step 9





Using screw (E) secure part (2) into parts (7,8) with hex key (F).

Step 10




Using bolt (G) attach L shape bracket (J) into parts (2) to parts (3,4) with hex key (F), then using cam lock (C) secure parts (3,4) into part (12) with Philips head screwdriver as per diagram.

Step 11





Using bolt (G) attach L shape bracket (J) into part (2) to parts (5,6) with hex key (F), then using cam lock (C) secure parts (5,6) into part (12) with Philips head screwdriver as per diagram.

Step 12




Using screw (K) secure parts (9,10) with Philip head screwdriver as per diagram.

Step 13




Using cam lock (C) secure part (1) into parts (7,8) with Philips head screwdriver , then using bolt (G) attach L shape bracket (J) into parts (3,4,5,6) to part (1) with hex key (F) .

Step 14




Place stickers cover the holes (D) as per diagram.

Step 15




Put fireplace insert as per diagram.

Step 16




Using screw (M) secure L shape bracket (L) into part (7) with Philip head screwdriver.

Step 17



Put adjustable feet into the bottom and fully tighten as per diagram.

Step 18



Final Assembly