


# Item # : W60CMP

## Assembly Instructions




Walker Edison®

*Please visit our website for the most current instructions, assembly tips, report damage, or request parts. [www.walkeredison.com](http://www.walkeredison.com)*


Revised 02/03/2020 (I)

# General Assembly Guidelines


- I. Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- IV. The three main types of hardware used to assemble this product are : wood dowels , screws and bolts.
- V. The provided glue is to secure wood dowels in place . When first inserting dowels , locate the appropriate hole for the dowel , place a small amount of glue in the hole and insert the dowel . Wipe away excess glue immediately.




In future assembly steps when dowels are necessary to attach assembly parts together , place a small amount of glue on the end of the dowel before attaching parts together . Wipe away excess glue immediately.




- VI. A Phillips head screwdriver is required for the assembly of this product .




# Parts List



# Hardware List


A		Ø8x30mm	Wooden dowel	38	pcs
B		Ø6x35mm	Cam bolt	30	pcs
C		Ø15x11mm	Cam lock	22	pcs
D		Ø15x9mm	Cam lock	8	pcs
E		Ø30mm	Sticker	34	pcs
F		Ø6x50mm	Bolt	16	pcs
G		M4	Hex Key	1	pc
H		Ø5x16mm	Shelf support pin	8	pcs
J		Ø3x17mm	Screw	12	pcs
K			Plastic wedge	12	pcs
L		Ø3x12mm	Screw	24	pcs
M		Ø4x38mm	Screw	8	pcs
N			Handle	2	pcs
P		Ø4x22mm	Handle Bolt	4	pcs
Q			Glue tube	1	pc
R			Left Glide Track	2	pcs
S			Left Glide Runner	2	pcs
T			Right Glide Track	2	pcs
U			Right Glide Runner	2	pcs



Philips head screwdriver required for assembly  
(not included)


*The hardware quantities listed above are required for proper assembly.  
Some extra hardware may also have been included.*

# Step 1



Secure cam bolt (B) into part (1) with Philips head screwdriver as per diagram.


## Step 2



Using screw (F) attach part (10) into part (14) with hex key (G) as per diagram.


# Step 3

2X




Insert wooden dowel (A) into parts (4,5) as per diagram.

# Step 4




Insert wooden dowel (A) into parts (2,3) ,then secure cam bolt (B) into parts (2,3) with Philips head screwdriver as per diagram.

# Step 5




Insert wooden dowel (A) into parts (11,12,13) as per diagram.

# Step 6





Using screw (L) attach part (R) to parts (2,11) , part (T) to parts (3,11) with Philips head screwdriver as per diagram.

# Step 7





Insert wooden dowel (A) into part (8), then secure cam bolt (B) into part (8) with Philips head screwdriver as per diagram.

# Step 8





Using cam lock (C) secure parts (2,3) to part (8) with Philips head screwdriver as per diagram.

# Step 9





Using cam lock (C) secure part (11) to part (8) with Philips head screwdriver as per diagram.

# Step 10




Put part (9) as per diagram.

# Step 11




Using cam lock(C) secure parts (4,5) to parts (2,3) with Philips head screwdriver as per diagram.

# Step 12




Using bolt (F) attach part (10) to parts (2,3,4,5,11) with hex key (G) as per diagram.

# Step 13





Using bolt (F) attach part (10) to parts (12,13) with hex key (G) as per diagram.

# Step 14




Put part (7) as per diagram.

# Step 15






Using cam lock(C) secure part (1) to parts (2,3,4,5) with Philips head screwdriver as per diagram.

# Step 16



Insert shelf support pin (H) into parts (4,5) as per diagram. Make sure you place the four shelf support pins (H) in the same level. So the shelf is not titled .Put part (6) into unit as per diagram. Tilt and rest the adjustable shelf (6) onto the shelf support pins .


# Step 17



Using screw (J) secure plastic wedge (K) with Philips head screwdriver as per diagram.

# Step 18


2X



Using screw (L) attach part (S) to part (16), part (U) to part (17) with Philips head screwdriver as per diagram.


# Step 19

2X




Using screw (M) attach parts (16,17) to part (15) with Philips head screwdriver as per diagram.

# Step 20





Put part (18) as per diagram.

# Step 21




Secure cam bolt (B) into parts (19,20), then using handle bolt (P) secure handle (N) to parts (19,20) with Philips head screwdriver as per diagram.

# Step 22





Using cam lock(D) secure parts (19,20) to parts (16,17) with Philips head screwdriver as per diagram.

# Step 23




Place sticker (E) cover the holes as per diagram .

# Step 24



Assembled the drawers as per diagram

# Step 25



# Final Assembly