


Item # : AF24NYM2D

Assembly Instructions




Walker Edison®

*Please visit our website for the most current instructions, assembly tips, report damage, or request parts. **www.walkeredison.com***


Revised 29/11/2019 (I)

General Assembly Guidelines


- I. Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- IV. The three main types of hardware used to assemble this product are : wood dowels , screws and bolts.
- V. The provided glue is to secure wood dowels in place . When first inserting dowels , locate the appropriate hole for the dowel , place a small amount of glue in the hole and insert the dowel . Wipe away excess glue immediately.




In future assembly steps when dowels are necessary to attach assembly parts together , place a small amount of glue on the end of the dowel before attaching parts together . Wipe away excess glue immediately.




- VI. A Phillips head screwdriver is required for the assembly of this product .




- VI|. Power tools should not be used to assemble this product .




- VIII. Concealed hinges are three-way adjustable.



Horizontal
by screw adjustment




In-and-Out
by loosening the hinge-arm
mounting screw or via cam
adjustment























Vertical
Via slots in the mounting
plate or via cam adjustment

Parts List



Hardware List


A		Ø8x30mm	Wooden dowel	6	pcs
B		Ø6x35mm	Cam bolt	4	pcs
C		Ø15x11mm	Cam lock	4	pcs
D		Ø30mm	Sticker	4	pcs
E		Ø6x50mm	Screw	4	pcs
F			Shelf support pin	4	pcs
G		Ø5x12mm	Screw	4	pcs
H		Ø6x25mm	Bolt	8	pcs
J		Ø4x45mm	Screw	3	pcs
K			Plastic wedge	6	pcs
L		Ø3x17mm	Screw	6	pcs
M		M4	Hex Key	1	pc
N			Europe hinge	4	pcs
P		Ø3.5x14mm	Screw	24	pcs
Q			Velcro strap	1	pc
R			Nut	1	pc
S		Ø4x25mm	Screw	1	pc
T		Ø4x15mm	Screw	1	pc
U			Glue tube	1	pc



Philips head screwdriver required for assembly
(not included)


*The hardware quantities listed above are required for proper assembly.
Some extra hardware may also have been included.*

Step 1




Insert wooden dowel (A) into parts (2,3,4) as per diagram.

Step 2




Secure cam bolt (B) into part (1), then using screw (J) attach part (2) to part (1) with Philips head screwdriver as per diagram.

Step 3




Using cam lock(C) secure part (4) to part (1) with Philips head screwdriver as per diagram.

Step 4




Using cam lock(C) secure part (3) to part (1) with Philips head screwdriver as per diagram.

Step 5




Put part (5) as per diagram.

Step 6




Put part (6) as per diagram.

Step 7




Using bolt (H) attach part (13) to parts (11,12) with hex key (M) as per diagram.

Step 8




Using bolt (H) attach part (13) into parts (11,12) with Hex key (M) as per diagram.

Step 9




Using screw (G) attach part (11) to part (10) with Philips head screwdriver.

Step 10






Using screw (E) attach part (13) into parts (3,4) with hex key (M) as per diagram.

Step 11




Place sticker (D) cover the holes as per diagram .

Step 12




Using screw (L) fix plastic wedge (K) to back panel with Philips head screwdriver as per diagram.

Step 13




Insert shelf support pin (F) into parts (3,4) as per diagram.
Make sure you place the four shelf support pins in the same level .So the shelf is not tilted .
Tilt and rest shelf .Put part (9) on the shelf support pins as per diagram.

Step 14




Using screw (P) attach Europe hinge (N) into parts (7,8) with Philips head screwdriver as per diagram.

Step 15




Using screw (P) attach Europe hinge (N) into part (4) with Philips head screwdriver as per diagram.

Step 16



Using screw (P) attach Europe hinge (N) into part (3) with Philips head screwdriver as per diagram. Open and close the doors .If necessary ,adjust the screws for a good fit .


Step 17



Using screw (T) attach Velcro strap (Q) into part (1) with Philips head screwdriver as per diagram.


Step 18

WARNING




Serious or fatal injuries can occur from furniture tipping over. To prevent the furniture from tipping over we recommend that it is permanently fixed to the wall. Wall anchor and hardware are included with this product. Please make sure hardware is suitable for your walls before installing, as different wall materials may require different types of anchors.

Wall



Using screw (S) attach Velcro strap (Q) into Nut (R) to wall with Philips head screwdriver as per diagram.

Step 19



Final Assembly