


# Item # : W48FPCLCR Assembly Instructions




Walker Edison®

Please visit our website for the most current instructions, assembly tips, report damage, or request parts. [www.walkerediton.com](http://www.walkerediton.com)


Revised 22/05/2020(C)

# General Assembly Guidelines


- I. Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- IV. The three main types of hardware used to assemble this product are: wood dowels, screws and bolts.
- V. The provided glue is to secure wood dowels in place. When first inserting dowels, locate the appropriate hole for the dowel, place a small amount of glue in the hole and insert the dowel. Wipe away excess glue immediately.




In future assembly steps when dowels are necessary to attach assembly parts together, place a small amount of glue on the end of the dowel before attaching parts together. Wipe away excess glue immediately.



- VI. A Phillips head screwdriver is required for the assembly of this product .




- VII. Power tools should not be used to assemble this product.






- VIII. Drill may be needed for securing product to wall.

# Parts List



# Hardware List


A		Ø8x30mm	Wooden dowel	32 pcs
B		Ø15x11mm	Cam lock	23 pcs
C		Ø15x9mm	Cam lock	4 pcs
D		Ø6x35mm	Cam bolt	27 pcs
E		Ø6x50mm	Screw	20 pcs
F		M 4	Hex Key	1 pc
G		Ø6x13mm	Bolt	16 pcs
H		Ø30mm	Sticker	27 pcs
J		Ø4x12mm	Screw	4 pcs
K			L shape bracket	2 pcs
L		F18V66L	Fireplace Insert	1 pc
M			Glue tube	1 pc



Philips head screwdriver required for assembly  
(not included)


*The hardware quantities listed above are required for proper assembly.  
Some extra hardware may also have been included.*

# Step 1






Insert wooden dowel (A) into parts (2,4,11,12) ,then secure cam bolt (D) into parts (7,8) with Philips head screwdriver as per diagram.

# Step 2





Insert wooden dowel (A) into parts (3,9,10) ,then secure cam bolt (D) into parts (3,9,10) with Philips head screwdriver as per diagram.

# Step 3





Secure cam bolt (D) into part (1) ,then using cam lock (B) secure part (2) to part (1) with Philips head screwdriver as per diagram.

# Step 4





Using cam lock (B) secure part (8) to part (10) ,part (7) to part (9) with Philips head screwdriver as per diagram.

# Step 5




Using cam lock (B) secure parts (3,9) to part (11) with Philips head screwdriver as per diagram.

# Step 6




Using cam lock (B) secure parts (3,10) to part (12)with Philips head screwdriver as per diagram.

# Step 7




Using screw (E) attach part (6) to part (10) , part (5) to part (9) with hex key (F) as per diagram.

# Step 8





Using screw (E) attach part (13) to parts (3,4,5,6,9,10) with hex key (F) as per diagram.

# Step 9




Using bolt (G) attach part (14) to part (13) with hex key (F) as per diagram.

# Step 10




Using cam lock (B) secure part (1) to parts (3,9,10) , cam lock (C) secure part (1) to part (4) with Philips head screwdriver as per diagram.

# Step 11





Place sticker (H) cover the holes as per diagram .

# Step 12





Insert the fireplace (L) to unit as per diagram.

# Step 13




Using screw (J) attach L shape bracket (K) to part (9) with Philips head screwdriver as per diagram.

# Step 14




Repeat the last step as per diagram.

# Step 15



Position the assembled unit at the desired location ,if necessary adjust the floor leveler at the bottom of the support leg to level the unit .

# Step 16



## Final Assembly