


Item # : BS68VON

Assembly Instructions




Walker Edison®

*Please visit our website for the most current instructions, assembly tips, report damage, or request parts. **www.walkerediton.com***


Revised 20/04/2020 (L)

General Assembly Guidelines


- I. Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- IV. The three main types of hardware used to assemble this product are: wood dowels, screws and bolts.
- V. The provided glue is to secure wood dowels in place. When first inserting dowels, locate the appropriate hole for the dowel, place a small amount of glue in the hole and insert the dowel. Wipe away excess glue immediately.




In future assembly steps when dowels are necessary to attach assembly parts together, place a small amount of glue on the end of the dowel before attaching parts together. Wipe away excess glue immediately.



- VI. A Phillips head screwdriver is required for the assembly of this product .




- VII. Power tools should not be used to assemble this product.




















- VIII. Drill may be needed for securing product to wall.

Parts List



Hardware List


A		Ø8x30mm	Wooden dowel	16 pcs
B		Ø1/4"x12mm	Bolt	23 pcs
C		Ø1/4"x25mm	Bolt	8 pcs
D		Ø6x38mm	Screw	16 pcs
E		M4x10mm	Bolt	3 pcs
F			Nut	3 pcs
G		Ø3.5x12mm	Screw	8 pc
H		Ø1/4"x15mm	Bolt	1 pcs
J			Anchor	1 pc
K		Ø4x30mm	Screw	1 pc
L			Flat washer	1 pc
M			Bracket	1 pc
N			Hex Key	1 pc
P			Adjustable foot	4 pcs
Q			Wrench	1 pc
R			Glue tube	1 pc



Philips head screwdriver required for assembly
(not included)


*The hardware quantities listed above are required for proper assembly.
Some extra hardware may also have been included.*

Step 1




Insert wooden dowel (A) into parts (7,8,9,10) as per diagram.

Step 2




Using bolt (E) connect and secure both parts (6) with Nut (F) and Wrench (Q) as per diagram.
Note : Do not fully tighten all the bolts .

Step 3




Using bolt (B) attach part (3) to parts (4,5) ,then using bolt (H) attach bracket (M) into part (3) with hex key (N) as per diagram.

Step 4




Secure feet (P) at the bottom of parts (1,2) as per diagram.

Step 5




Using bolt (C) attach parts (1,2) to part (3) with hex key (N) as per diagram.

Step 6




Using screw (D) attach part (5) to part (10) ,bolt (B) attach part (10) to part (1) with hex key (N) as per diagram.

Step 7




Using screw (D) attach part (10) to part (8) ,bolt (B) attach part (8) to part (2) with hex key (N) as per diagram.

Step 8




Insert part (9) into part (8) ,then using screw (D) attach part (8) to part (9) ,bolt (B) attach part (9) to part (1) with hex key (N) as per diagram.

Step 9




Insert part (8) into part (9) ,then using screw (D) attach part (9) to part (8) ,bolt (B) attach part (8) to part (2) with hex key (N) as per diagram.

Step 10




Insert part (9) into part (8) ,then using screw (D) attach part (8) to part (9) ,bolt (B) attach part (9) to part (1) with hex key (N) as per diagram.

Step 11




Insert part (8) into part (9) ,then using screw (D) attach part (9) to part (8) ,bolt (B) attach part (8) to part (2) with hex key (N) as per diagram.

Step 12




Insert part (7) into part (8) ,then using screw (D) attach part (8) to part (7) with hex key (N) as per diagram.

Step 13




using screw (D) attach part (4) to part (7) with hex key (N) as per diagram.

Step 14




Using bolt (C) attach parts (1,2) to part (3) with hex key (N) as per diagram.
Note : Fully tighten all bolts.

Step 15



Using screw (G) attach parts (6,11) into parts (1,2) with Philips head screwdriver as per diagram.


Step 16



If necessary, adjust the pre-attached Floor Levelers at the bottom of metal legs to level the unit.


Step 17

WARNING




Serious or fatal injuries can occur from furniture tipping over. To prevent the furniture from tipping over we recommend that it is permanently fixed to the wall. Wall anchor and hardware are included with this product. Please make sure hardware is suitable for your walls before installing, as different wall materials may require different types of anchors.

Wall



Using screw (K) attach Flat washer (L) to bracket (M) to Wall anchor (J) to wall with Philips head screwdriver as per diagram.

Step 18



Final Assembly