


# Item # : W58ABMD

## Assembly Instructions




Walker Edison®

*Please visit our website for the most current instructions, assembly tips, report damage, or request parts. [www.walkerredison.com](http://www.walkerredison.com)*


Revised 24/10/2018

# General Assembly Guidelines


- I. Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- IV. The three main types of hardware used to assemble this product are : wood dowels , screws and bolts.
- V. The provided glue is to secure wood dowels in place . When first inserting dowels , locate the appropriate hole for the dowel , place a small amount of glue in the hole and insert the dowel . Wipe away excess glue immediately.




In future assembly steps when dowels are necessary to attach assembly parts together , place a small amount of glue on the end of the dowel before attaching parts together . Wipe away excess glue immediately.




- VI. A Phillips head screwdriver is required for the assembly of this product .



- VII. Power tools should not be used to assemble this product .




# Parts List



# Hardware List


A		Ø8x30mm	Wooden dowel	28 pcs
B		Ø6x35mm	Cam bolt	22 pcs
C		Ø15x11mm	Cam lock	22 pcs
D		Ø30mm	Sticker	22 pcs
E		Ø6x50mm	Shoulder Screw	6 pcs
F		M 4	Hex Key	1 pcs
G		Ø8x5x16mm	Shelf support pin	12 pcs
H			Door stopper	2 pcs
J			Hinge	4 pcs
K		Ø3x12mm	Screw	28 pcs
L		Ø3x15mm	Screw	4 pcs
M			Bolt	2 pcs
N			Handle	2 pcs
P		Ø4x22mm	Handle Bolt	4 pcs
Q		Ø3x17mm	Screw	8 pcs
R			Plastic wedge	8 pcs
S			Glue tube	1 pcs



Philips head screwdriver required for assembly  
(not included)


*The hardware quantities listed above are required for proper assembly.  
Some extra hardware may also have been included.*

# Step 1




Insert wooden dowel (A) into part (5,6,7).

# Step 2





Insert wooden dowel (A) into part (3,1,2,4,15), secure cam bolt (B) with screwdriver into part (3,1,2,4,15).

# Step 3




Use screwdriver to secure cam bolt (B) into part (9), use screw (L) secure door stopper (H) into part (9)

# Step 4





Attach parts (5),(6) to part(1,2,4,3,15) with cam lock (C)

# Step 5




Attach part (14) to part (10) using bolt (E) with hex key (F). Insert wooden dowel (A) to part(10)

# Step 6




Attach part (1,2,3,4) to part (10), then insert and secure cam lock (C) to part (10) to lock it.

# Step 7





Attach part (10) to parts (6,7) using bolt (E) with hex key (F).

# Step 8




Slide the back panel (11) all the way into the groove

# Step 9




Insert part (9) into part (5,6,7), then insert and secure cam lock (C) to part (5,6,7).

# Step 10




Secure plastic wedge (R) to back panel (11) using screw (Q) with screwdriver.

# Step 11




Place sticker (D) over holes as per diagram.

# Step 12




Insert shelf support pin (G) into part (5,6,7)

## Step 13




Then place shelf (12,13,8) on top of support pin (G)

# Step 14




Attach hinge (J) to part (16,17) using screw (K) with screwdriver.

# Step 15




Insert bolt (M) into part (16),(17) ,attach handle (N) to part (16,17) using handle bolt (P) with screwdriver.

# Step 16




Attach hinges(J) by using screw (K) as shown in the diagram.

# Step 17




Use screw (K) with screwdriver secure the hinge and door and secure door (16).

# Step 18



Under part (14) we have adjustable feet to fully support the box

# Step 19



## Final Assembly