


Item # : W70CSGD

Assembly Instructions




Walker Edison.

Please visit our website for the most current instructions, assembly tips, report damage, or request parts. www.walkerredison.com


Revised 27/08/2018

General Assembly Guidelines


- I. Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- IV. The three main types of hardware used to assemble this product are : wood dowels , screws and bolts.
- V. The provided glue is to secure wood dowels in place . When first inserting dowels , locate the appropriate hole for the dowel , place a small amount of glue in the hole and insert the dowel . Wipe away excess glue immediately.




In future assembly steps when dowels are necessary to attach assembly parts together , place a small amount of glue on the end of the dowel before attaching parts together . Wipe away excess glue immediately.




- VI. A Phillips head screwdriver is required for the assembly of this product .




- VII. Power tools should not be used to assemble this product .




- VIII. Concealed hinges are three-way adjustable.



Horizontal
by screw adjustment




In-and-Out
by loosening the hinge-arm
mounting screw or via cam
adjustment


















Vertical
Via slots in the mounting
plate or via cam adjustment

Parts List



Hardware List


A		Ø8x30mm	Wooden dowel	34 pcs
B		Ø6x35mm	Cam bolt	29 pcs
C		Ø15x11mm	Cam lock	29 pcs
D		Ø30mm	Sticker	29 pcs
E		Ø6x50mm	Bolt	6 pcs
F			Plastic wedge	12 pcs
G		Ø3x17mm	Screw	12 pcs
H			Handle	2 pcs
J		5/32x25mm	Bolt	4 pcs
K		Ø4mm	Hex Key	1 pcs
L			Glue tube	1 pcs
N			Hinge	4 pcs
P		Ø3.5x15mm	Screw	16 pcs
Q		Ø8x5x16mm	Shelf support pin	12 pcs



Philips head screwdriver required for assembly
(not included)


*The hardware quantities listed above are required for proper assembly.
Some extra hardware may also have been included.*

Step 1




Insert wooden dowel (A) and secure cam bolt (B) with screwdriver into part (1,2,3,4,8)

Step 2




Insert wooden dowel (A) into part (10,9,5,16).

Step 3





Insert wooden dowel(A) into part (7,17)

Step 4





Secure cam bolt (B) with screwdriver into part (6)

Step 5




Attach part (1,5,2) by using cam bolts (C)

Step 6




Attach part (3,16,4) by using cam bolts (C)

Step 7




Attach part (8,9,10) by using cam bolts (C)

Step 8




Attach part (17) to part (18) using bolt (E) with hex key (K).

Step 9





Attach part (9,10) to part (17) using bolt (E) with hex key (K).

Step 10





Attach Part (7) to Part (9,10) with fixed wooden dowel

Step 11




Attach part (1,2,7,17) by using cam bolts (C)

Step 12





Attach part (7,17,3,4) by using cam lock (C)

Step 13




Slide back panel (11,12) into grooves to attach part (2,9,10,4)

Step 14





Attach part (6) to part (5,9,10,16) using cap Lock (C)

Step 15




Secure the back panel (11,12) by using the plastic wedge (F) and screw (G).

Step 16




Place sticker (D) Over holes as per diagram.

Step 17




Insert shelf support pin (Q) into part (1,2,9,10,4)

Step 18



Put Shelf (13,14) into the console .


Step 19



Insert door hinge (N) into part (15) with screw (P),



Secure Handle (H) with Bolt (J) into the Door frame

Step 20




Inset screw (P) to secure part (15) to part(5)

Step 21




Insert screw (P) to secure part (15) to part (16)

Step 22



Adjust part (18) to adjust stability

Step 23



Final Assembly