


# Item # : D42MX

## Assembly Instructions




Walker Edison®

Please visit our website for the most current instructions, assembly tips, report damage, or request parts. [www.walkeredison.com](http://www.walkeredison.com)


Revised 26/02/2019 (E)

# General Assembly Guidelines


- I. Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- IV. The three main types of hardware used to assemble this product are : wood dowels , screws and bolts.
- V. The provided glue is to secure wood dowels in place . When first inserting dowels , locate the appropriate hole for the dowel , place a small amount of glue in the hole and insert the dowel . Wipe away excess glue immediately.




In future assembly steps when dowels are necessary to attach assembly parts together , place a small amount of glue on the end of the dowel before attaching parts together . Wipe away excess glue immediately.




- VI. A Phillips head screwdriver is required for the assembly of this product .




- VII. Power tools should not be used to assemble this product .




# Parts List



# Hardware List


A		Ø8x30mm	Wooden dowel	20 pcs
B		Ø6x35mm	Cam bolt	25 pcs
C		Ø15x11mm	Cam lock	25 pcs
D		Ø30mm	Sticker	25 pcs
E		Ø6x50mm	Screw	5 pcs
F		M6x12mm	Bolt	16 pcs
G		M 4	Hex Key	1 pc
H			Glue tube	1 pc



Philips head screwdriver required for assembly  
(not included)


*The hardware quantities listed above are required for proper assembly.  
Some extra hardware may also have been included.*

# Step 1





1.Insert cam bolt B onto part (1) secure with Philips head screwdriver

# Step 2




2. Insert wooden dowel A to part (2,8) as per diagram

# Step 3




3. Insert wooden dowel A to part (3,9) per diagram

# Step 4




4. Insert wooden dowel A to part (4,5,6,7), and insert cam bolt B to part (4,5,6,7) secure with Philip head screwdriver as per diagram.

# Step 5




5. Attach part 2 onto part(9),insert bolt E secure with hex key G per diagram

# Step 6





6. Attach part (8) onto part (2), using bolt E secure with hex key G per diagram

# Step 7



7. Attach part (11) onto part (4,6) , insert bolt F secure with hex key G per diagram

# Step 8



8. Attach part (3) onto part (4,6), put cam bolt C onto part (3) and secure with Philips head screwdriver as per diagram.















# Step 15



15. Place the sticker D cover the holes per diagram

# Step 16



# Final Assembly