


# Item # : HT68SLAT

## Assembly Instructions




Walker Edison®

Please visit our website for the most current instructions, assembly tips, report damage, or request parts. [www.walkeredison.com](http://www.walkeredison.com)


Revised 13/06/2019(N)

# General Assembly Guidelines


- I. Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- IV. The three main types of hardware used to assemble this product are: wood dowels, screws and bolts.
- V. The provided glue is to secure wood dowels in place. When first inserting dowels, locate the appropriate hole for the dowel, place a small amount of glue in the hole and insert the dowel. Wipe away excess glue immediately.




In future assembly steps when dowels are necessary to attach assembly parts together, place a small amount of glue on the end of the dowel before attaching parts together. Wipe away excess glue immediately.



- VI. A Phillips head screwdriver is required for the assembly of this product .




- VII. Power tools should not be used to assemble this product.







- VIII. Drill may be needed for securing product to wall.

# Parts List



# Hardware List


A		Ø1/4"x12mm	Bolt	9 pcs
B		Ø1/4"x25mm	Bolt	12 pcs
C		Ø1/4"x45mm	Bolt	12 pcs
D			Nut	12 pcs
E		Ø4x30mm	Screw	1 pc
F			Anchor	1 pc
G		Ø6x16mm	Washer	1 pc
H			Bracket	1 pc
J			Hex key	1 pc



Philips head screwdriver required for assembly  
(not included)


*The hardware quantities listed above are required for proper assembly.  
Some extra hardware may also have been included.*

# Step 1




Using bolt (B) secure parts (4,11) into part (9) with hex key (J) as per diagram.

## Step 2




Using bolt (B) secure parts (9,10) into part (8) with hex key (J) as per diagram.

## Step 3



Using bolt (A) secure part (5) into parts (4,11) with hex key (J) as per diagram.


## Step 4



Using bolt (A) secure (3,12) into part (4,11) with hex key (J) as per diagram.




## Step 5




Insert nut (D) into part (2) ,Using bolt (C) secure (3,12) into part (2) ,then using bolt (A) secure part (1) into parts (3,12) with hex key (J) as per diagram.

## Step 6



Put part (6,7) into part (2) as per diagram.


## Step 7




Using bolt (A) secure bracket (H) into part (1) with hex key (J) as per diagram.

## Step 8


### WARNING



Serious or fatal injuries can occur from furniture tipping over. To prevent the furniture from tipping over we recommend that it is permanently fixed to the wall. Wall anchor and hardware are included with this product. Please make sure hardware is suitable for your walls before installing, as different wall materials may require different types of anchors.




Wall



Using screw (E) into washer (G) to anchor (F) to wall with Philip head screwdriver as per diagram.

## Step 9



## Final Assembly