



1 Attach the runners K to pieces 2 and 3 as shown. Use screws (L).




2 On piece 6, attach the door handles (D) using screws (E), attach bar hinges (O). On piece 12, attach the door handles (G) using screws (F) & washer (P).




A		12PCS
B		12PCS
C		12PCS
D		1 PC
E		1 PC
F		2 PCS
G		2 PCS
H		1 PC
I		2 PCS
J		8 PCS

K		1 PCS
L		12PCS
M		4 PCS
N		20PCS
O		2 PCS
P		2 PCS


- 3** On piece 1, secure the catch (H) using screws (I). Use the pre-drilled holes for guidance.




- 4** Attach piece 2 & 3 to piece 4 using wooden dowels (C), cam dowels (A) and cam locks (B).




- 5** Slot piece 7 into the ridges. Add piece 1 to the unit using wooden dowels (C), cam dowels (A) and cam locks (B). Connect door 6 using bar hinges (O).




- 6** Slot piece 8 into the ridges. Add piece 5 to the unit using wooden dowels (C), screw (J).




7 Attach metal plate (M) to piece 5 using screws (N).




8 Tighten the leg (14) clockwise direction.




9 Attach pieces 9, 10 & 11 using screws (J). Make sure that the built-in ridge is facing inwards and at the bottom.




10 Slot piece 13 into the ridges. First insert the cam locks (B) into the pre-drilled holes on parts 10 & 11. Then insert cam dowels (A) into each side, you then need to line up these screws with the pre-drilled holes on the front piece (12). Once attached, tighten the cam locks (B) using a cross-head screwdriver and ensure the piece is secure.



- 11** Turn the drawer upside down. Line up the holes on the outside pieces with the holes on the runners (KDR & KDL), secure to the drawer using screws (L).



- 12** Turn the unit the right way up and insert the drawers.



- 13** The unit should now be assembled and ready to use.

