


Item # : BU60ROG3D

Assembly Instructions




Walker Edison®

Please visit our website for the most current instructions, assembly tips, report damage, or request parts. www.walkeredison.com


Revised 06/11/2019(L)

General Assembly Guidelines


- I. Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- IV. The three main types of hardware used to assemble this product are: wood dowels, screws and bolts.
- V. The provided glue is to secure wood dowels in place. When first inserting dowels, locate the appropriate hole for the dowel, place a small amount of glue in the hole and insert the dowel. Wipe away excess glue immediately.




In future assembly steps when dowels are necessary to attach assembly parts together, place a small amount of glue on the end of the dowel before attaching parts together. Wipe away excess glue immediately.



- VI. A Phillips head screwdriver is required for the assembly of this product.




- VII. Power tools should not be used to assemble this product.




- VIII. Drill may be needed for securing product to wall.


- IX. Concealed hinges are three-way adjustable.



Horizontal
by screw adjustment




In-and-Out
by loosening the hinge-arm
mounting screw or via cam
adjustment





Vertical
Via slots in the mounting
plate or via cam adjustment

Parts List



Hardware List


A		Ø8x30mm	Wooden dowel	24 pcs
B		Ø6x35mm	Cam bolt	16 pcs
C		Ø15x11mm	Cam lock	16 pcs
D			Sticker	16 pcs
E		Ø6x50mm	Screw	8 pcs
F		M 4	Hex Key	1 pc
G		Ø6x12mm	Bolt	20 pcs
H			Europe Hinge	4 pcs
J		Ø3.5x14mm	Screw	24 pcs
K			Handle	3 pc
L		Ø4x22mm	Handle Bolt	3 pcs
M			Door stopper	1 pcs
N		Ø3.5x14mm	Screw(Black)	2 pcs
P			Bolt	2 pcs
Q			Plastic wedge	14 pcs
R		Ø3x17mm	Screw	14 pcs
S			Pulley	2 pcs
T			Pulley	2 pcs
U		Ø3x12mm	Screw	16 pcs
V			Shelf support pin	12 pcs
W			Glue tube	1 pc



Philips head screwdriver required for assembly
(not included)


*The hardware quantities listed above are required for proper assembly.
Some extra hardware may also have been included.*

Step 1





Insert wooden dowel (A) into parts (11,13), using screw black (N) attach Door stopper (M) to part (11), then secure cam bolt (B) into part (1) with Philips head screwdriver as per diagram.

Step 2





Insert wooden dowel (A) into parts (3,4,5,6), then secure cam bolt (B) into parts (3,4,5,6) with Philips head screwdriver as per diagram.

Step 3




Using cam lock(C) secure parts (5,6) to part (13) with Philips head screwdriver as per diagram.

Step 4




Using cam lock(C) secure parts (3,4) to part (11) with Philips head screwdriver as per diagram.

Step 5




Put part (8) as per diagram.

Step 6




Using screw (E) attach part (2) into parts (3,4,5,6) with hex key (F) as per diagram.

Step 7





Using bolt (G) attach parts (19,20) to part (2) with hex key (F) as per diagram.
Note : fully tighten all the bolts .

Step 8




Put parts (7,9) as per diagram.

Step 9




Using cam lock (C) secure part (1) to parts (3,4,5,6) with Philips head screwdriver as per diagram.

Step 10




Place sticker (D) cover the holes as per diagram .

Step 11




Using screw (R) secure plastic wedge (Q) with Philips head screwdriver as per diagram.

Step 12




Insert shelf support pin (V) into parts (3,4,5) as per diagram.

Step 13




Put parts (12,14) into unit as per diagram.

Step 14




Put part (15) into unit as per diagram.

Step 15




Using screw (J) attach Europe hinge (H) , handle bolt (L) attach handle (K) into parts (16,17) with Philips head screwdriver as per diagram.

Step 16




Using screw (J) attach Europe hinge (H) into part (3) with Philips head screwdriver as per diagram.

Step 17




Using screw (J) attach Europe hinge (H) into part (4) with Philips head screwdriver as per diagram.

Step 18




Using screw (U) attach pulley (T,S) to part (18) , secure bolt (P) into part (18) ,then using handle bolt (L) attach handle (K) into part (18) with Philips head screwdriver as per diagram.

Step 19



Pick up the door (18), and fit the pulley (T) over the slider rails on the bottom panel (2) , then place the pulley (S) into top panel (1) , till it click into pulley (T) as per diagram.

Step 20



Final Assembly