



# ASSEMBLY INSTRUCTIONS

LWYE 5540 / 5542 / 5544 - 32 / 7 / 9

QUEEN CORVED HEADBOARD / FOOTBOARD / SIDE RAIL















SKU # 33355404 / 33355428 / 33355442 / 32755401 / 32755425 / 32755449

/ 32955405 / 32955429 / 32955443


Manufactured by (LWYE) for ROOMS TO GO

Version 1.0 4/2025


Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts. Which may have come loose inside the carton during shipment. Identify and count all parts and compare with the hardware list below :

Hardware List	No.	Picture	Description	Dimension	Qty
	①		JCBB BOLT	M8 x P1.25 x 40mm	6 PCS
	②		M4 C.S.K SCREW	4 x 32MM	6 PCS
	③		M5 ALLEN WRENCH	5 x 65MM	1 PC
	④		BUTTON		4 PCS
	⑤		PHILIPS HEAD SCREWDRIVER	NOT PROVIDED	1 PC
Parts List			Description		Qty
	A		HEADBOARD PANEL		1 PC
	B		HEADBOARD LEG (LEFT)		1 PC
	C		HEADBOARD LEG (RIGHT)		1 PC
	D		BASE RAIL		1 PC
	E		FOOTBOARD		1 PC
	F		SIDE RAIL		2 PCS
	G		WOODEN SLAT		5 PCS
	H		WOODEN SLAT SUPPORT		5 PCS
	I		CONNECTOR WOODEN SUPPORT		5 PCS




\* Hardware pack in carton - SKU # 32755401 / 32755425 / 32755449



OPTION 1





OPTION 2




	Picture	Description	Dimension	Qty
Pre - Assemble Hardware		JCBB BOLT	M8 x P1.25 x 20mm	8 PCS
		SPRING WASHER	M8 x 15mm	8 PCS
		FLAT WASHER	M8 x 22mm	8 PCS




# ASSEMBLY STEP


STEP 1 : Assemble Base Rail (D) to Headboard Leg Left (B) and Headboard Leg Right (C).

Hardware List		
	Description	Qty
 ①	JCBB BOLT	2 PCS
 ③	M5 ALLEN WRENCH	1 PC





STEP 2 : Assemble Headboard Panel (A) to leg. Loosen JCBB Screw at Headboard & Footboard (A). Slot in side rail (B) and tighten back JCBB Screw.


Hardware List		
	Description	Qty
 ①	JCBB BOLT	6 PCS
 ③	M5 ALLEN WRENCH	1 PC
 ④	BUTTON	4 PCS



# ASSEMBLY STEP


STEP 3 : Assemble wooden slat support (H) to wooden slat (G). Assemble wooden slat (G) to bed.

Hardware List		
	Description	Qty
 ②	M4 C.S.K SCREW	6 PCS
 ⑤	PHILIP HEAD SCREWDRIVER (NOT PROVIDED)	1 PC



STEP 4 : Assemble wooden slat support (H) to wooden slat (G). Assemble wooden slat (G) to bed.


Hardware List		
	Description	Qty
 ②	M4 C.S.K SCREW	6 PCS
 ⑤	PHILIP HEAD SCREWDRIVER (NOT PROVIDED)	1 PC



# ASSEMBLY STEP

## OPTION 1

STEP 5 : After assembly, adjust leveler, it found uneven levelness on product due to uneven floor.



## OPTION 2

STEP 5 : After assembly, adjust leveler, it found uneven levelness on product due to uneven floor.

